


## SVEA WXS 1,425



Hot Dip Galvanized





Steel/Concrete







655


[mm]




## Assembly



Couplers must be engaged!





## Adjustment range





## Lifting


Worxsafe Lifting Scissors  
Part no. 833412



## Lifting Forks



## Inspection



Check for:

- Cracks in concrete, especially around the groove for lifting scissor.
- Broken welds.
- Cracked sheet metal.
- Worn rubber feet, the feet are replaceable.


When in doubt what is resolvable, always check with the manufacturer.

## GENERAL

- Always read the manufacturer's instructions to ensure that the product is used correctly and safely.
- Do not use the product in any way other than mentioned in this user instruction.
- If anything is unclear, contact the manufacturer or your retailer.
- Never mix products from different manufacturers.
- Do not exceed the specified load limits.

## STORAGE

- Store as far as possible in non-corrosive environment.
- Store the products according to the manufacturer's intended way for example when stacking to minimize the risk of personal injury.

|                                                                                     |                              |                                                                                     |           |                                                                                       |                        |
|-------------------------------------------------------------------------------------|------------------------------|-------------------------------------------------------------------------------------|-----------|---------------------------------------------------------------------------------------|------------------------|
|    | Technical information        |    | Weight    |    | Tighten with torque    |
|  | Inspect                      |   | Recycling |   | Loosen                 |
|  | Inspection interval (days)   |  | Correct   |  | Max allowed wind speed |
|  | Inspection interval (months) |  | Incorrect |  | Force                  |
|  | Inspect straightness         |  | Be aware! |  | Torque                 |
|  | Inspect for cracks           |  | Tighten   |  | Insert                 |
|  | Anchorage                    |  | Tether    |  | Click/Press            |